

MILKSECURE™ DASHBOARD USER PERMISSIONS MATRIX

Permissions	Roles							
	Super Admin	Regional Manager	Dealer	Dealer Technician	Dairy Admin	Dairy Operator	Sanitarian	Milk Hauler
Add Super Admin	✓	✗	✗	✗	✗	✗	✗	✗
Add/Delete Region	✓	✗	✗	✗	✗	✗	✗	✗
Add/Delete Regional Manager	✓	✗	✗	✗	✗	✗	✗	✗
Add/Delete Dealer	✓	✓	✗	✗	✗	✗	✗	✗
Add/Delete Dealer Technician	✓	✓	✓	✗	✗	✗	✗	✗
Add Dairy Admin	✓	✓	✓	✗	✗	✗	✗	✗
Edit/Delete Dairy Admin	✓	✓	✓	✗	✗	✗	✗	✗
Add Dairy	✓	✓	✓	✗	✗	✗	✗	✗
Edit/Delete Dairy	✓	✓	✓	✓	✗	✗	✗	✗
Add/Delete Farm User	✓	✓	✓	✓	✓	✓	✗	✗
Enable Sanitarian Role	✓	✓	✓	✓	✓	✓	✗	✗
Enable Hauler/Processor Role	✓	✓	✓	✓	✓	✓	✗	✗
View Raw Registers	✓	✓	✓	✓	✗	✗	✗	✗
Add/Delete Tanks	✓	✓	✓	✓	✓	✓	✗	✗
Download Tank Data	✓	✓	✓	✓	✓	✓	✓	✓
Download Condensing Unit Data	✓	✓	✓	✓	✗	✗	✗	✗
Add/Delete Custom Alerts	✓	✓	✓	✓	✓	✓	✗	✓

- In the matrix above, permissions are indicated by a “✓” in the column beneath each specified user role.
- Each dairy must have a Dairy Administrator. The Dairy Administrator must agree to the End-User License Agreement (EULA) when the dairy is registered on the MilkSecure website/dashboard.